

IMPORTANT!

Please read this document before using your FloorWindo®

"If the instructions for use, assembly and maintenance are not carried out, Windo® Displays, the manufacturer and its distributors are not liable. Windo® Displays, its distributors and the manufacturer are never liable for indirect damages".

INSTRUCTIONS FOR USE, ASSEMBLY AND MAINTENANCE

- Remove the foil from the FloorfiX™ grid on the back side of the FloorWindo® before using.
- Please ensure that the ink on the printed poster is completely dry (at least 24 hours) before inserting into FloorWindo®.
- Recommended weight of paper for poster is 135 grams.
- Place the FloorWindo® only on a dust-free, dry and flat surface.
- Use FloorWindo® in dry conditions only.
- Windo® Displays recommends to place the FloorWindo® just outside of high-traffic walking areas. This will help increase the life of the FloorWindo® while still creating maximum impact for your advertising message.
- Clean the FloorWindo® on a regular basis, your advertising message deserves it!
- To clean the FloorWindo®, use any a non-scratching detergent and a clean dry cloth.
- Never use a damaged FloorWindo®
- Always store your Windo® poster display flat.
- Poster size: A1 = 594 x 841 mm



Exchange the poster like this



Always keep your FloorWindo® clean



File these instructions for later use.

Visit www.windodisplays.com for information.




IMPORTANT!

Please read this document before using your FloorWindo®

"If the instructions for use, assembly and maintenance are not carried out, Windo® Displays, the manufacturer and its distributors are not liable. Windo® Displays, its distributors and the manufacturer are never liable for indirect damages".

INSTRUCTIONS FOR USE, ASSEMBLY AND MAINTENANCE

- Remove the foil from the FloorfiX™ grid on the back side of the FloorWindo® before using.
- Please ensure that the ink on the printed poster is completely dry (at least 24 hours) before inserting into FloorWindo®.
- Recommended weight of paper for poster is 135 grams.
- Place the FloorWindo® only on a dust-free, dry and flat surface.
- Use FloorWindo® in dry conditions only.
- Windo® Displays recommends to place the FloorWindo® just outside of high-traffic walking areas. This will help increase the life of the FloorWindo® while still creating maximum impact for your advertising message.
- Clean the FloorWindo® on a regular basis, your advertising message deserves it!
- To clean the FloorWindo®, use any a non-scratching detergent and a clean dry cloth.
- Never use a damaged FloorWindo®
- Always store your Windo® poster display flat.
- Poster size: 4A4 = 297 x 841 mm



1 Locate the opening under the LogoLip



2 Slide the back panel from under the opening and lift the window away from the poster



3 Exchange the poster like this



4 Always keep your FloorWindo® clean



File these instructions for later use.

Visit www.windodisplays.com for information.